

Before you begin, read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference and parts ordering information.

Kit Components:

<u>Qty.</u>	<u>Part Description</u>
1	Windshield
4	3/8 –18 flange nuts
2	Lower support rods
2	Upper support rods
4	Grommets
4	Grommet spacers
4	¼ - 20 x ¾” Phillips screws
4	¼” flat washers
4	U-clamps
4	Beveled spacers
4	Eyebolts
4	Allen screws
1	Allen wrench

Tools required for installation:

- #2 Phillips screw driver
- 9/16” Wrench

IMPORTANT: Perform all tasks correctly and completely.

INSTALLATION INSTRUCTIONS

1. First, prepare windshield assembly. Install the short lower rods and the long upper rods to the windshield by pressing the four rubber grommets into holes in the windshield. Insert the four aluminum spacers into the grommets from the backside. Install the support rods to the back of the windshield using four ¼ - 20 screws and four ¼” washers. Long rods on top, short rods on the bottom as shown in Illustration #1 and tighten with a screwdriver.
2. Install handlebar clamps to the machine by installing the four U-clamps on the handlebars from the front so that the open end is toward the rear of the machine. Install the eyebolt, and beveled washers. Position the lower clamp so the eyebolt hole is on the bottom side of the handlebar and close to the lower bend. Position top clamp so that eyebolt hole is on the topside of the handlebar near the top bend. Consult Illustration #2 on the procedure.
3. Install windshield to the machine by passing the support rods on the windshield through the holes in the eyebolts. Upper support rods go on the top side of the handlebars. Lower rods go on the bottom side of the handlebars. Secure with Allen screws.

4. Align the windshield to suit your preference. Using a 9/16 wrench, lightly tighten the nuts on the clamps to hold the windshield in place. Check for clearances when turning handlebars from side to side. Make final adjustments, and then tighten clamps firmly to secure windshield into place.

NOTE: It is acceptable to experiment with clamp placement and to trim support rod length to come up with the best fit. For removal for trailering, or seasonal storage remove the four quick release knobs, then remove the windshield and rods from the clamps. Leave clamps on handlebars for future installation.

